

Step1: Remove the existing overflow cover first.



Step 2: Unscrew the plastic overflow part from the overflow pipe.



Step 3: Unscrew the overflow pipe that connects with the waste, and then remove the whole overflow pipe from the bath.



Step 4: Remove the existing waste from the bath.



Step 5: Install the replacement overflow part and overflow pipe. Silicone should be applied on the overflow hoses. This step requires two people. One person holds the overflow pipe on the back side, the other tightens the overflow part from the inside of the bath.





Step 6: Install the replacement waste onto the bath.



Step 7: Connect the overflow pipe to the waste.

