
# Installation Instruction

### Single Handle Kitchen Faucet



# Replacement Parts


Keep this manual for ordering replacement parts.




### NO NAME

- 1. Aerator
- 2. Spout
- 3. Anti-friction gasket
- 4. Plastic lock ring
- 5. O-ring
- 6. Plastic lock ring
- 7. Faucet body
- 8. Cartridge
- 9. Screw
- 10. Lock nut
- 11. Cartridge holder
- 12. Handle
- 13. Screw
- 14. Handle knob
- 15. Pendestal
- 16. O-ring
- 17. Rubber gasket
- 18. Stainless steel gasket
- 19. Lock screw
- 20. Lock nut
- 21. Hose

# Product Dimension Drawing







# Faucet Installation Procedures









Step ②



Step ③




Step ④




# Faucet Installation Procedures









Step ②




Step ③





Step ④




# Product Dimension Drawing







### Step 9



### Notice:

Please removing all of the sand, silt and other things from the water hose before assembling, to avoid blocking the faucet and effecting water rate. Please use the special tools to disassemble it and wash with pneumatic equipment, if the faucet blocked.