



Note:
For the each part, the dimension tolerance should be followed the list below.

0 ~ 100	101 ~ 200	201 ~ 400	e401
±1	±2	±3	±5

For the finished assembly, the dimension tolerance should be followed the list below.

0 ~ 300	e301
±2	±5

**STHFW6190 - STHFW6190F -STHFW6190MB - STHFW6190V
HIGH FLOW WASTE WITH CONNECTOR**