

Outdoor Shower Maintenance

1. Before installation, flush and clean the water supply pipes thoroughly to prevent dirt or debris from entering the shower system and damaging the cartridges.
2. Use only clean water with the outdoor shower. Dirty or contaminated water may damage the cartridges, braided hoses, spray nozzles, and other components.
3. The recommended operating water pressure is between 3 and 6 bar. If the water pressure is below 2 bar or is unstable, a suitable pump may be required to ensure proper performance.
4. This outdoor shower is made from 316L stainless steel, which offers excellent corrosion resistance. However, if installed near the sea or in a coastal environment, corrosion may still occur over time if the shower is not cleaned regularly. After each use: Rinse the shower with fresh water, dry the surface with a soft cloth. Residues from shampoo, soap, shower gel, and salt deposits can damage the stainless-steel finish if left on the surface for extended periods.
5. If the outdoor shower will not be used for an extended period, cover it with a suitable protective cover or store it indoors. Prolonged exposure to sun, rain, and other weather conditions may affect the appearance and lifespan of the product, especially for coloured finishes.
6. **During winter, remove the shower and store it indoors before freezing temperatures occur.** Failure to do so may result in damage to the cartridges and other internal components caused by frost.
7. If any leaks occur after installation, check that all connections have been tightened correctly. Every outdoor shower is pressure-tested and inspected for leaks before packaging and shipment.
8. Keep all spare parts and accessories supplied with the product in a safe place for future maintenance or replacement needs.